

BOARD SERIAL NUMBERS

PRE/POST UL

REPRESENTED
WITH 2 LETTER
CODE
BP = PRE-UL
UL = UL

YEAR

REPRESENTED
WITH A LETTER
A= 2018
B = 2019
C = 2020
ETC.

WEEK

REPRESENTED
WITH A 2-DIGIT
NUMBER
31 = JULY 30 - AUG 3
32 = AUG 6 - AUG 10
ETC.

AC/DC

AC OR DC
MACHINE
SL-100/150
SW-300/350
A = AC
D = DC

HP

HORSEPOWER
DC PCB ONLY
SL-150 / SW-350
2 = 1/2 HP
4 = 1 HP

OPERATOR TYPE

REPRESENTED
WITH 2-DIGIT
LETTER CODE
45 = SL-45 ONLY
SL = SLIDE GATE
SW = SWING GATE
OH = OVERHEAD
TO = TORO

SERIAL NUMBER

REPRESENTED
WITH 4 OR 5
DIGIT NUMBER

EXAMPLES (ALL BOARDS WITH SERIAL NUMBER 21000)

UL BOARD FOR SL-45 - AUGUST 1, 2018
ULA314521000

PRE-UL AC BOARD FOR SL-100 - AUGUST 1, 2018
BPA31ASL21000

UL AC BOARD FOR SW-300 - AUGUST 6, 2018
ULA32ASW21000

UL 1/2 HP DC BOARD FOR SL-90 - SEPTEMBER 10, 2018
ULA37D2SL21000

PRE-UL 1 HP DC BOARD FOR SW-350 DC - SEPTEMBER 17, 2018
BPA38D4SW21000

NOTES:

- FIRMWARE REVISION IS PRINTED ON MICROPROCESSOR
- ENTRAPMENT PROTECTION DEVICES:
 - A MINIMUM OF (2) MONITORED ENTRAPMENT PROTECTION DEVICES ARE **REQUIRED** FOR EACH ENTRAPMENT ZONE (LOCATION OR POINT OF CONTACT WHERE A PERSON CAN BECOME ENTRAPPED BETWEEN A MOVING GATE AND A RIGID OBJECT)
 - THE OPERATOR IS EQUIPPED WITH AN INHERENT ENTRAPMENT PROTECTION SYSTEM (ERD). EXTERNAL MONITORED ENTRAPMENT PROTECTION DEVICES (EDGE OR NON-CONTACT PHOTOELECTRIC SENSOR) ARE REQUIRED AS FOLLOWS FOR NORMAL GATE OPERATION:
 - 2018 SLIDE GATES: (2) DEVICES REQUIRED. ONE FOR THE OPENING CYCLE AND 1 FOR THE CLOSING CYCLE.
 - 2018 SWING GATES: (1) DEVICE REQUIRED FOR THE CLOSING CYCLE. IF THERE IS AN OBSTRUCTION THAT CREATES AN ENTRAPMENT ZONE IN THE OPEN CYCLE. IN THOSE CASES, A SECOND DEVICE IS REQUIRED.